

Detroit Tuned Gen 1 Beltline Blackout Kit



Thank you for purchasing the Detroit Tuned Beltline Blackout Kit. This kit will fit all gen 1 cars (R50, R52, & R53). It comes with 25 feet of high quality 3M Striping Tape. Your car has 8 breaks in the belt line where the doors, boot, & bonnet open. We gave you enough tape to extend 1 inch past each break. Your tape may also have a top protective layer; this will need to be removed after the install. You will need a very sharp knife or razor blade to trim the ends. It is easier to trim the end of the tape after the protective layer is removed.

Wash and dry the car before starting this operation. If possible, use an air compressor to blow all the water out from this area. Sometimes, you may need to let the car sit overnight in a garage to insure the car is dry. The presence of water will prevent the tape from adhering properly. It is also highly advisable to thoroughly clean each molding with a wax and grease remover and a lint free paper towel. You can get these items at any auto parts or paint supply store. A few extra steps to make sure the area is clean, dry, and contaminate free, will make the tape last for a long time without coming off. Also, wash and dry your hands just before starting to apply the tape. Do the install in a cool dry place free from wind and dirt. **DO NOT INSTALL IN THE SUN!** Be in a shaded area and work in small sections.

Detroit Tuned cannot be held responsible for the quality of the install or the longevity of the tape due to preparation. If you need help, look in the phone book for a graphic installer, sign shop, or tint shop in your area and they should be able to help you. When installed correctly, this tape will last the life of the car!

If you have any questions, feel free to give us a call here at Detroit Tuned Monday-Friday 9am-6pm EST.