

# Detroit Tuned Oil Counter Rest How-To For All Gen 1 MIN Cooper's

## Resetting the MINI Oil Indicator:

**You will find** this useful if you do your own oil changes. Keep in mind you should wait until your factory service expires, since resetting the indicator may lead the dealer to deny oil changes since the indicator does not indicate an oil change is due.

- 1 - Press and hold the trip odometer button.
- 2 - Insert car key and turn it to the first position (not the second position).
- 3 - You will see 51A come up in the trip odometer area.
- 4 - Release, then press and hold again.
- 5 - Watch for the word "RST" to appear on the Odometer indicator.
- 6 - Release, then press and hold again.
- 7 - Wait for the "RST" message to flash.
- 8 - Release, and then press & release (once only).

**The Service interval is now reset** to 10,000 miles for the first time you do this function or 15,500 for every other time you rest it. Keep in minds that if you're having the dealer do every other service, do not reset it. The dealer will not do an oil service unless it read that they should do so.

**Detroit Tuned highly recommends** changing your oil every 5,000 actual miles. As well as using a high quality synthetic oil of your choice and a MINI brand filter.

**If you have any questions**, feel free to give us a call here at Detroit Tuned Monday-Friday 8am-6pm EST.